

General Operation

Soft Keys

Soft keys appear at the bottom of the display panel and correspond to the F1 through F6 keys. The function of each soft key changes for each task. Refer to the "Step-By-Step Messaging Guide" section for details.

Startup Screen

```
*****
* 3LM2730CM FW/HW version 1.93k/11 *
*   @ R u d , I n c   *
*****
Please select one of the application
options below using the F1 through F6
keys
MSG  FORM  LOG      SET
```

This is the default screen when the iDT 3000 turns on. From the Startup Screen you can choose MSG (F1), FORM (F2), LOG (F3), or SET (F6). The Startup Screen is the starting point for sending forms or setting functions.

Messaging Screen

Please select one of the options below using the F1 through F6 keys

```
INBOX  NEW  SAUED  SPCL1  SPCL2  BACK
```

This is the screen that appears when you press MSG (F1) from the Startup Screen. It provides the options: INBOX (F1), NEW (F2), SAUED (F3), SPCL1 (F4), SPCL2 (F5) or BACK (F6). The Messaging Screen is the main starting point for reading and sending messages.

SPCL1 (F4) and/or SPCL2 (F5) may be defined by your administrator for frequently used messages.

Alphanumeric Keypad

- Your administrator defines whether a field accepts alpha, numeric or Yes/No entries.
- To enter a letter, press the corresponding key on the number keypad repeatedly and quickly to select the desired letter (e.g. for the letter "L" press the "5" key until the "L" is displayed).
- To enter a number, simply press the corresponding number key on the keypad.
- For Yes/No field, press any key on the keypad to toggle between Y and N.

Note: If you have the add-on optional keyboard, you may use it instead of the iDT's alphanumeric keypad.

For customer support on the iDT 3000, please contact:

- 1-877-428-7623 (U.S.)
- 0845 3371661 (U.K.)
- 1300 255477 (AUS)

Trimble Mobile Resource Management is a leading, global provider of solutions for GPS fleet tracking, automated scheduling and dispatch, and remote vehicle management. Our solutions are designed to help your business lower operation costs, increase productivity and enhance customer service by making it easier for you to manage your mobile workers, your mobile workers' work and your mobile workers' assets in the field.



Copyright © 2009 Trimble Navigation Limited. All rights reserved. Trimble, the Globe & Triangle logo and iLM are registered trademarks of Trimble Navigation Limited.

QRG-ict3000-4Nov09US



900-0029-000 Rev B



Step-By-Step Messaging Guide

Reading Messages

Press **MSG** (F1) from the Startup Screen (default) to get to the Messaging Screen.

- Press **INBOX** (F1) to pull up the messages in the inbox. Unread messages are marked with an asterisk (*).
- Use the scroll knob or the **NEXT** (F1) and **PREV** (F2) keys to scroll through the messages.
- Once the desired message is highlighted, press **VIEW** (F3) to open the message.

Saving Messages

*Note: Up to 10 messages can be saved. You can save messages directly from the **INBOX**, or from **VIEW** mode.*

- From the **INBOX**, highlight the message you want to save.
- Press **SAVE** (F4). The message is marked “s” for saved.
- From **VIEW** mode, press **SV/UNS** (F2). This changes the message status from unsaved to saved, or back to unsaved.
- To view all saved messages, start from the **MSG** window and press **SAVED** (F3).

Deleting Messages

*Note: Saved messages cannot be deleted. To “unsave” a message, highlight it and press the **SAVE** key to unsave it.*

- From the **INBOX**, highlight the message you want to delete using the scroll knob or the **NEXT** (F1) and **PREV** (F2) keys.

- Press **VIEW** (F3) to open the message.
- Press **DEL** (F3) to remove the current message.
- A message delete confirmation pops up:
 - Press 1 on the alphanumeric keypad to confirm the delete request.
 - Press 2 on the alphanumeric keypad to cancel the delete request.

Sending Messages

Start at the Messaging Screen.

- Press **NEW** (F2) to bring up the list of pre-defined messages.
- Press **NEXT** (F1) and **PREV** (F2) or use the scroll knob to highlight the desired pre-defined message.
- Press **SELECT** (F3) to choose the highlighted message. In some cases, this will automatically send the message.
- If a second screen with a cursor prompt pops up (as defined by your administrator), you can add characters prior to the message being sent (see alphanumeric entry section).
- Press **CNCL** (F2) to cancel the pre-defined message and return to the previous message screen.
- Press **SEND** (F1) to send the message along with the additional note.

Sending Forms

Start from the Startup Screen.

- Press **FORM** (F2).
- Press **NEXT** (F1) and **PREV** (F2) or use the scroll knob to scroll through the pre-defined forms.
- Press **SELECT** (F3) to choose the highlighted form.

- Use the alphanumeric keypad to add characters to the form.
 - Press **SPACE** (F3) to insert a space between characters or to move the cursor one character to the right.
 - Press **BKSPC** (F4) to move the cursor back one space or character.
 - Use **NEXT** (F1) and **PREV** (F2) to move from one field to the next.
- Press **SEND** (F5) to send the completed form. An error message pops up if **SEND** is pressed without completing all required fields.

Setting Manual Functions

From the Startup Screen, press **SET** (F6) to change various settings of the iDT 3000. Use the alphanumeric keypad to choose the desired function.

- Press 1 to turn off the back display light.
- Press 2 to turn on the back display light.
- Press 3 to **CLICK ON/OFF** the click function. This changes the default beep to a click.
- Press 4 to turn **ON/OFF** the optional bar code function.
- Press 5 on the keypad to view the messages in the **MSG Queue**. These are messages currently held in the iLM®’s memory that will be sent as soon as cellular coverage is available.
- Press 6 to turn **ON/OFF** the key lock. This locks or unlocks the optional keyboard.